

Draco tera – Tera Viewer

Release Notes

System Requirements
Microsoft Windows <ul style="list-style-type: none"> Windows 8, Windows 8.1, Windows 10 Free memory of 512 MB recommended macOS <ul style="list-style-type: none"> macOS 10.14 (Mojave) or higher Free memory of 512 MB recommended Intel Platform Java <ul style="list-style-type: none"> The Oracle Java Runtime Environment (JRE) 1.8.x, is the minimum version required. However, we strongly recommend the last version of Oracle Java 1.8 update 152, or the latest Oracle Java 9. (http://www.java.com)

Changes		
Date	Version	Change
2021-01-13	4.0.0.0	Features and enhancements: Support of new matrix firmware V04.00
2020-08-21	3.8.0.0	Features and enhancements: <ul style="list-style-type: none"> Support of new matrix firmware V03.08
2019-02-18	3.6.1.0	Features and enhancements: <ul style="list-style-type: none"> Support of encrypted data transfer on Linux CPU boards Improvements: <ul style="list-style-type: none"> Switching: No switching to unconnected extenders. Reason: Switching to unconnected extenders causes delay
2018-11-23	3.6.0.1	Improvements: <ul style="list-style-type: none"> Designer - Settings: Added URL prefix Fixes: <ul style="list-style-type: none"> Fixed Set As Default and Delete Default
2018-08-06	3.6.0.0	Features and enhancements: <ul style="list-style-type: none"> Support of new matrix firmware V03.06 New Designer layout New Designer features (add image) Improvements: <ul style="list-style-type: none"> Screen Settings: reduce options for already existing screens Fixes: <ul style="list-style-type: none"> Fixed scrollbars Validator: no check of existing CPU's for CPU Scanner und CPU Monitor

2018-01-22	3.5.3.0	Features and enhancements: <ul style="list-style-type: none"> • New CPU Monitor Improvements: <ul style="list-style-type: none"> • Optimized support of multi head devices • Reduced matrix load, due to optimized switching Fixes: <ul style="list-style-type: none"> • CPU list: Sometimes the preview image didn't match to the cpu device
2017-11-06	3.5.2.0	Features and enhancements: <ul style="list-style-type: none"> • Operator Console: Mouse Double Click into a screen will establish KVM connect via Matrix to defined Operator Console. • Full Screen Mode (F11): Option to enlarge the canvas to full screen
2017-09-12	3.5.1.0	Features and enhancements: <ul style="list-style-type: none"> • New Flat UI • Extras – Options: Show/Hide toolbar
2017-06-19	3.5.0.0	Features and enhancements: <ul style="list-style-type: none"> • Support of new matrix firmware V03.05 • New CPU Scanner Improvements: <ul style="list-style-type: none"> • Display information in virtual screen when extender is not available • Renamed Settings Parameters (Screenview -> Thumbview, Preview -> Liveview)
2017-03-16	3.4.1.0	<p>New layout format! Old format (*.dtl) is not compatible to new format (*.dvl).</p> Features and enhancements: <ul style="list-style-type: none"> • Changed layout file format from *.dtl to *.dvl • New designer features (auxiliary lines, copy and paste of multiple selection)
2017-01-16	3.4.0.0	Features and enhancements: <ul style="list-style-type: none"> • Support new matrix firmware V03.04
2016-11-01	3.3.0.0	Features and enhancements: <ul style="list-style-type: none"> • IP based monitoring and switching of CPUs and consoles • Configurable screen layouts • Live preview • Switching per drag & drop • Setting default layout on matrix